



Application Instructions

All surfaces must be considered dirty and must be cleaned prior to the application of vinyl. Cleaners such as Windex are acceptable, however, we recommend a 2 to 1 mixture of water and isopropyl alcohol. Wipe the surface dry with a clean, dry, lint-free cloth.

Air and surface temperature must be above 55 degrees Fahrenheit for the application of the vinyl. Apply the vinyl using the following steps:

Note: It is recommended that a novice installer have a helper present on the following steps. It is not a requirement however it will help insure a quality installation.

1. Measure and mark the area you wish to apply your vinyl using a water-soluble pencil. (Using caution in this step will help assure a level application.) Once you have the overall area defined and marked you should have a good idea as to where the upper right and left corners of the decal should be placed. At this time take your decal (paper and all) and tape the right upper corner of it to your predetermined area. Have your assistant hold the upper left corner of the decal in place while you stand back a few feet and look at it. If you like it's placement move on to step 2
2. Tape the left corner in place and put a piece of tape down the center of the decal. At this time using your water-soluble pencil place a mark on the right and left side of the decal. Make sure you mark both the tape and the surface you are mounting the decal to. You will be aligning these two marks later so make sure you can see them.
3. On the Left side of the decal hold the paper and peel off the tape until you reach the center of the decal. (The decal should stay stuck to the application tape at this time) Cut the paper as close to the center as you can without scratching your surface.
4. Spray the surface on the left side with a light soapy water or application fluid (we recommend the application fluid) Note: do not spray water or application fluid when using reflective vinyl, reflective vinyl should be applied on dry surface. Place the left side of the decal down on the surface, taking care to line up the lines you drew in step 2. With the application tape still intact, squeegee the decal to the surface by applying pressure and smooth even strokes. Start at the middle of the decal and work your way out to the left.
5. Lift up the right hand side of the decal and remove the remainder of the backing paper. (It is ok to lift up the piece of center tape at this time). Apply your application fluid to the right hand surface. Place the right hand decal taking care to align your marks on the right hand side. Again, start at the middle and squeegee toward the right hand side of the decal.
6. It is a good Idea to wait just a couple of minutes before you remove the application tape. This allows the application fluid to dry some and will prevent the decal from trying to come up. Once it is adhering to the surface squeegee the entire decal a second time. Then, carefully peel the tape off the entire decal.
7. It is common for they're to be some small bubbles throughout the decal. These bubbles will leave by themselves within a few weeks. If you have any major bubbles you can eliminate them by carefully heating the area with a hair dryer or heat gun, and then puncturing them with a needle and applying pressure with your thumb.

Note: You can do more damage than good by chasing the smaller bubbles. They will leave by themselves as the vinyl breathes and the application fluid evaporates.

If you have questions about or any problems with these decals do not hesitate to call: 978-319-9666.